

## AQUA LIP

### 10.089.02 C96

- Claims:**
- Introduction of approximately 2% of water through a lamellar gel
  - Intense color
  - Soft and slippery at the application
  - Plumping effect

| PHASE    | INGREDIENT                  | INCI NAME  | SUPPLIER                       | %            |
|----------|-----------------------------|--|--------------------------------|--------------|
| <b>A</b> | Cerilla Raffinee Paillettes | Euphorbia Cerifera (Candelilla) Wax  | Baerlocher                     | 9.00         |
|          | Polarwachs® N364            | Microcrystalline Wax   | Maprecos                       | 4.40         |
|          | Cerozo MA/C                 | Ozokerite  | Baerlocher                     | 2.50         |
|          | Cerauba T1                  | Copernicia Cerifera (Carnauba) Wax   | Baerlocher                     | 2.50         |
|          | Eutanol® G                  | Octyldodecanol   | BASF                           | 10.00        |
|          | Myritol® 331                | Cocoglycerides   | BASF                           | 5.00         |
|          | Cetiol® CC                  | Dicaprylyl Carbonate   | BASF                           | 4.00         |
|          | Cetiol® Sensoft             | Propylheptyl Caprylate   | BASF                           | 6.00         |
|          | Salacos® 43V                | Polyglyceryl-2 Triisostearate  | The Nisshin Oil Group          | 26.35        |
| <b>B</b> | Unipure Red LC 3079         | CI 15850   | Sensient®Cosmetic Technologies | 1.80         |
|          | Unipure White LC 981        | CI 77891   | Sensient®Cosmetic Technologies | 4.50         |
|          | Unipure Black LC 989        | CI 77499   | Sensient®Cosmetic Technologies | 0.15         |
|          | <b>Amisol™ Duo</b>          | <b>Lecithin (and) Polyglyceryl-3 Palmitate</b>                               | <b>Lucas Meyer Cosmetics</b>   | <b>3.70</b>  |
|          | <b>Emulmetik™ 100</b>       | <b>Lecithin</b>  | <b>Lucas Meyer Cosmetics</b>   | <b>14.80</b> |
| <b>C</b> | Vitapherole® E1000          | Tocopherol (and) Helianthus Annuus (Sunflower) Seed Oil                      | VitaeNaturals                  | 0.50         |
|          | Gourmandise 3155/6          | Fragrance  | Vanessence                     | 0.50         |
| <b>D</b> | <b>Sculptessence™</b>       | <b>Water (and) Glycerin (and) Linum Usitatissimum (Linseed) Seed Extract</b> | <b>Lucas Meyer Cosmetics</b>   | <b>1.30</b>  |
|          | Deionized Water             | Water  | -                              | 1.00         |
|          | Zemea® Propanediol          | Propanediol  | Dupont Tate & Lyle             | 1.00         |
|          | <b>Biophilic™ H</b>         | <b>Hydrogenated Lecithin (and) C12-16 Alcohols (and) Palmitic Acid</b>       | <b>Lucas Meyer Cosmetics</b>   | <b>0.80</b>  |
|          | Dermosoft® 1388             | Glycerin (and) Water (and) Sodium Levulinate (and) Sodium Anisate            | Dr Straetmans*                 | 0.20         |

**Manufacturing Procedure:**

1. Prepare phase D:
  - a. Heat D up to 70-75°C.
  - b. Mix D under slow stirring for 20 minutes to hydrate phospholipids.
  - c. Cool down under slow stirring.
2. Prepare phase B: grind each pigment in a mixture of 80% Emulmetik™ 100 and 20% Amisol™ Duo.
3. Put silicone oil spray in mould and put mould in oven at 45°C.
4. Melt phase A with B at 85-90°C under slow stirring.
5. Cool down to 70-75°C.
6. Add C and D into AB under slow stirring and mix for 3 minutes.
7. Take mould out of oven and pour the formula.
8. Let cool down for 10 minutes.
9. Take the top part of the formula out of mould with spatula.
10. Put mould in freezer at -18°C for 10 minutes.
11. Turn out lipsticks from mould and put lipsticks in cases.

**Formula Specifications:**

Aspect: Burgundy stick.

\* = Distributed in France by Lucas Meyer Cosmetics