

MY BEAUTIFYING LOOSE POWDER

17.256.01 C140

- Claims:**
- Treating powder that bypasses the problematic of introducing liquid hydrosoluble active ingredients in anhydrous products

PHASE	INGREDIENT	INCI NAME	SUPPLIER	%
A	Talc Luzenac Pharma M	Talc	Imerys	80.50
	SP-10	Nylon-12	Kobo	5.00
	Kobomica S-25	Mica	Kobo	2.00
	MSS 500W	Silica	Kobo	2.00
	SJ Touch 1	Polymethyl Methacrylate	Azelis	2.00
B	Matipure™ Oil Free	Magnesium Aluminum Silicate (and)	Lucas Meyer Cosmetics	3.00
	ChroNOLine™	Hydroxyethylcellulose (and) Phospholipids	Lucas Meyer Cosmetics	3.00
C	Unipure Yellow LC181	CI 77492	Sensient® Cosmetic Technologies	1.00
	Unipure Red LC3079	CI 15850	Sensient® Cosmetic Technologies	0.10
	Unipure Black LC989EM	CI 77499 (and) Silica	Sensient® Cosmetic Technologies	0.10
D	Verstatil PC	Phenoxyethanol (and) Caprylyl Glycol	Dr Straetmans	1.00
	SG 32609	Fragrance	Sozio	0.30

Manufacturing Procedure:

- Prepare B: adsorb ChroNOLine™ on Matipure™ Oil Free using an appropriate mixer.
- Prepare phases A and B.
- Mix the two phases until the product is homogeneous.
- Add the components of C and D into AB and mix until the product is homogeneous.

Formula Specifications:

Aspect: Beige-pink homogeneous powder.
 Viscosity (Rheo ELV 8, spindle 4, 6 rpm, 3 mn): NA
 pH: NA
 Preservative efficacy test: NA

Stability Tests: On lab batch up to 800 g
 Centrifugation (3000 rpm, 20 mn): NA
 Up to 1 month at 50°C
 Up to 3 months at: Room Temperature, 4-8°C and 45°C